



LED Cloud User Guide

Used to control portable LED screens remotely from the cloud via
Google Chrome browser on any type of device

Video Format - .mp4

Photo Format - .jpeg

Standard Screen Resolution - 192 x 640px

Wide Screen Resolution - 320 x 640px

Window Series Resolution - 320 x 576px


Video Display Hire & Sales

1300 98 94 99


www.videodisplay.com.au

STEP ONE

Go to the URL on Chrome below and enter your username and password you have been given
URL - <https://www.led-cloud.com/#/Account/Login>




If necessary change the language to English by clicking as below




STEP TWO

Select **SOURCE** then **UPLOAD MATERIALS** to upload your content onto the cloud.



STEP THREE

Select **Program** then **New Program** to add new content



STEP FOUR

Add a program name and set the size of your screen.

New Program ×

Program Name:


Resolution:

	Width	Height	
	<input type="text" value="192"/>	<input type="text" value="640"/>	Select Device ▼

Type Selection:

STEP FIVE


Add your image or video and then select the **four cross** button to make full screen.



STEP SIX


On the right hand side click the **cross** under Video to select the video you uploaded earlier.

▼ Video



Update Video

Materials ✕



File Name	Size	Uploader	Upload Time
VDH Hire.mp4	6.6 MB	IpswichJets	2021/11/26 14:13:15
Spinning Wheel Video Mock Up Ver2.mp4	5.8 MB	VideoDisplayHire	2021/10/21 13:23:13
VDH Hire.mp4	6.6 MB	VDHTech	2021/10/20 16:52:01
test store screen - Wayne Hamlet.mp4	6.1 MB	VDHTech	2021/10/20 16:41:06
VDH Hire.mp4	6.6 MB	VideoDisplayHire	2021/10/19 14:36:42

< 1 > 25 Item / Page ▾


Cancel OK

STEP SEVEN

SAVE the program then click the **OFF** cross.

STEP EIGHT

Select the program you wish to send to a screen and then select **Batch Release**




The screenshot shows a web interface for managing programs. At the top, there are tabs for 'FullColorPrograms' and 'SingleDoubleColorProgram'. Below the tabs is a 'New Program' button and a search bar. On the right side, there are buttons for 'Bind to Playlist', 'Batch Release' (circled in red), and 'Delete'. Below this is a table with the following data:

ID	Program Name	Type	Resolution	Duration (s)	Creator	Modified Time	Status	Options
27379 2	LED Christmas Artwork	Full color	192x640	4	VideoDisplayHire	2021/11/26 14:18:45		Preview Edit More

STEP NINE

Select the screen you wish to send content to and click **INSERT** then click **SEND**



The screenshot shows a 'Send Program' dialog box. At the top, there are two toggle switches: 'Insert' (circled in red and turned on) and 'Additional Update' (turned off). Below the toggles is a search bar for 'Device ID, Device Name' and a 'Selected:2' indicator. On the left, there is a tree view of devices with the following structure:

- All 2
 - NZ Clients 0
 - Aussie Clients 2
 - show 0
 - Ipswich Jets 2
 - A4-21-A06CE IpswichJets1 (circled in red)
 - A4-21-A099E IpswichJets
 - Ungrouped 0

On the right, there is a table with the following data:

ID	Program Name	Playing time
273792	LED Christmas Artwork	4Second

At the bottom of the dialog, there is a 'Drag programs to sort' button and a 'Total Duration: 4Second' label. At the bottom right, there are 'Cancel' and 'Send' (circled in red) buttons.